

Model 422E21

In-Line Charge Converter

Installation and Operating Manual

For assistance with the operation of this product, contact PCB Piezotronics, Inc.

Toll-free: 800-828-8840 24-hour SensorLine: 716-684-0001 Fax: 716-684-0987 E-mail: info@pcb.com Web: www.pcb.com





PCB PIEZOTRONICS

Warranty, Service, Repair, and Return Policies and Instructions

The information contained in this document supersedes all similar information that may be found elsewhere in this manual.

Total Customer Satisfaction – PCB Piezotronics guarantees Total Customer Satisfaction. If, at any time, for any reason, you are not completely satisfied with any PCB product, PCB will repair, replace, or exchange it at no charge. You may also choose to have your purchase price refunded in lieu of the repair, replacement, or exchange of the product.

Service – Due to the sophisticated nature of the sensors and associated instrumentation provided by PCB Piezotronics, user servicing or repair is not recommended and, if attempted, may void the factory warranty. Routine maintenance, such as the cleaning of electrical connectors, housings, and mounting surfaces with solutions and techniques that will not harm the physical material of construction, is acceptable. Caution should be observed to insure that liquids are not permitted to migrate into devices that are not hermetically sealed. Such devices should only be wiped with a dampened cloth and never submerged or have liquids poured upon them.

Repair – In the event that equipment becomes damaged or ceases to operate, arrangements should be made to return the equipment to PCB Piezotronics for repair. User servicing or repair is not recommended and, if attempted, may void the factory warranty. Calibration - Routine calibration of sensors and associated instrumentation is recommended as this helps build confidence in measurement accuracy and acquired Equipment data. calibration cycles are typically established by the users own quality regimen. When in doubt about a calibration cycle, a good "rule of thumb" is to recalibrate on an annual basis. It is also good practice to recalibrate after exposure to any severe temperature shock, extreme. load. or other environmental influence, or prior to any critical test.

PCB Piezotronics maintains an ISO-9001 certified metrology laboratory and offers calibration services, which are accredited by A2LA to ISO/IEC 17025. with full traceability to SI through N.I.S.T. In addition to the normally supplied calibration, special testing is also available, such as: sensitivity at elevated or cryogenic temperatures, phase response, extended high or low frequency response, extended range, leak testing, hydrostatic pressure testing, and others. For information on standard recalibration services or special testing, contact your local PCB Piezotronics distributor, sales representative. or factory customer service representative.

Returning Equipment – Following these procedures will insure that your returned materials are handled in the most expedient manner. Before

equipment to PCB returning any Piezotronics, local contact vour distributor. sales representative, or factory customer service representative to obtain a Return Warranty, Service, Repair, and Return Policies and **Instructions** Materials Authorization (RMA) Number. This RMA number should be clearly marked on the outside of all package(s) and on the packing list(s) accompanying the shipment. A detailed account of the nature of the problem(s) being experienced with the equipment should also be included inside the package(s) containing any returned materials.

A Purchase Order, included with the returned materials, will expedite the turn-around of serviced equipment. It is recommended to include authorization on the Purchase Order for PCB to proceed with any repairs, as long as they do not exceed 50% of the replacement cost of the returned item(s). PCB will provide a price quotation or replacement recommendation for any item whose repair costs would exceed 50% of replacement cost, or any item that is not economically feasible to repair. For routine calibration services, the include Purchase Order should authorization to proceed and return at current pricing, which can be obtained a factory customer service from representative.

Warranty – All equipment and repair services provided by PCB Piezotronics, Inc. are covered by a limited warranty against defective material and workmanship for a period of one year from date of original purchase. Contact PCB for a complete statement of our warranty. Expendable items, such as batteries and mounting hardware, are not covered by warranty. Mechanical damage to equipment due to improper use is not covered by warranty. Electronic circuitry failure caused by the introduction of unregulated or improper excitation power or electrostatic discharge is not covered by warranty.

Contact Information – International customers should direct all inquiries to their local distributor or sales office. A complete list of distributors and offices found can be at www.pcb.com. Customers within the United States may contact their local sales representative or а factorv customer service representative. A complete list of sales can be representatives found at www.pcb.com. Toll-free telephone numbers for a factory customer service representative. in the division responsible for this product, can be found on the title page at the front of this manual. Our ship to address and general contact numbers are:

PCB Piezotronics, Inc. 3425 Walden Ave. Depew, NY14043 USA Toll-free: (800) 828-8840 24-hour SensorLineSM: (716) 684-0001 Website: www.pcb.com E-mail: info@pcb.com



PCB工业监视和测量设备 - 中国RoHS2公布表 PCB Industrial Monitoring and Measuring Equipment - China RoHS 2 Disclosure Table

				7	有害物 质	
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴 联苯 (PBB)	多溴二苯醚 (PBDE)
住房	0	0	0	0	0	0
PCB板	Х	0	0	0	0	0
电气连接器	0	0	0	0	0	0
压电晶体	Х	0	0	0	0	0
环氧	0	0	0	0	0	0
铁氟龙	0	0	0	0	0	0
电子	0	0	0	0	0	0
厚膜基板	0	0	Х	0	0	0
电线	0	0	0	0	0	0
电缆	Х	0	0	0	0	0
塑料	0	0	0	0	0	0
焊接	Х	0	0	0	0	0
铜合金 /黄 铜	Х	0	0	0	0	0
本表格依据 SJ/T	11364 的规注	定编制。				
〇:表示 该有害物	协质在该部件	所有均质	贡材料中	的含量均在 GB/T 2	6572 规定的限量要求以	下。
X:表示该有害物	顺至少在该	部件的事	其一均质;	材料中的含量超出	GB/T 26572 规定的限量	要求。
铅是欧洲RoHS指	令2011/65/	EU附件:	三和附件	四目前由于允 许的	豁免。	

CHINA RoHS COMPLIANCE

Component Name			Haza	rdous Substance	es	
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI Compounds (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	0	0	0	0	0	0
PCB Board	Х	0	0	0	0	0
Electrical Connectors	0	0	0	0	0	0
Piezoelectric Crystals	X	0	0	0	0	0
Ероху	0	0	0	0	0	0
Teflon	0	0	0	0	0	0
Electronics	0	0	0	0	0	0
Thick Film Substrate	0	0	Х	0	0	0
Wires	0	0	0	0	0	0
Cables	Х	0	0	0	0	0
Plastic	0	0	0	0	0	0
Solder	Х	0	0	0	0	0
Copper Alloy/Brass	Х	0	0	0	0	0

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement of GB/T 26572.

Lead is present due to allowed exemption in Annex III or Annex IV of the European RoHS Directive 2011/65/EU.

DOCUMENT NUMBER: 21354 DOCUMENT REVISION: C ECN: 45605



The Model 422E In-Line Charge Converter



Operating Guide with Enclosed Warranty Information

3425 Walden Avenue, Depew, New York 14043-2495

Phone 716 684-0001

Fax 716 684-0987

E-Mail electronics@pcb.com

Toll Free Line 1-800-828-8840

24 Hour Sensor Line 716 684-0001

MANUAL NUMBER: 18882 MANUAL REVISION: A ECN: 24741



table of contents

Introduction	page 3
Description	page 3
Installation	page 3
Operation	page 3
Calculation of Output Scaling	page 4
TEDS Functionality	page 4
Special Considerations	page 5
422E Series Models for Use with High Temperature Sensors	page 5
422E Series Models for Use in Radioactive Environments	page 6
ESD Warning Information	page 6

warranty/servicing

Warranty, Service & Return Procedure	page	7
Customer Service	page	8



introduction

The 422E series in-line charge converters are designed to convert the high impedance of a charge mode piezoelectric transducer to a low-impedance voltage by means of an ICP ® signal conditioner. These units may be used with either quartz or ceramic charge-mode piezoelectric sensors.

description

The 422E series in-line charge amplifiers operate from an ICP ® signal conditioner. The unit employs a high gain amplifier to perform the impedance transformation. The charge output of the transducers may be scaled in terms of acceleration, pressure or force. The output is then mV/g, mV/psi or mV/lb, respectively.

installation

Connect the 422E series to the transducer with low-noise cable (003A) only. Standard coaxial or twowire cable may be used between the amplifier and the signal conditioner, and between the signal conditioner and the readout device.

Note: For optimum noise performance, the cable length between the sensor and the 422E should be minimized.

operation

To operate, simply connect the input of the 422E to the transducer using low-noise (003A) cable and the output to any ICP ® signal conditioner using standard cable. The output of the signal conditioner may then be connected to an oscilloscope or other monitoring device. This output will be an AC signal (see *specification* for actual frequency response) with a DC bias. Many PCB signal conditioners remove the bias via an AC coupling circuit.



calculation of output scaling

The 422E contains a high-gain, low-noise amplifier connected in a charge amplifier configuration. The charge output of the transducer is transferred to the feedback capacitor of the amplifier to develop a voltage which may be calculated using the following equation.

*V*_{out} = 422E Scaling (*mV*/*pC*) x Transducer Sensitivity (*pC*/Engineering Unit)

where:

Vout = Output of 422E in mV/Engineering Unit

the Engineering Unit may be g's, Newtons, psi, etc., depending on the sensor

Example: A 357A12 (3 pC/g) is used with a 422E02 (10 mV/pC). Calculate the output in mV/g.

Answer: 10 mV/pC x 3 pC/g = 30 mV/g

TEDS functionality

422E units with a "T" prefix incorporate TEDS (Transducer Electronic Data Sheet) technology. Using a TEDS capable signal conditioner, or TEDS reader, the user is able to read calibration data stored in the sensor. Some systems allow the user to also write user data and calibration information to the 422E. All data is formatted in accordance with IEEE 1451.4.



special considerations

High source capacitance may degrade the performance of the 422E (source capacitance is the input capacitance defined as transducer capacitance + cable capacitance). In particular, noise may increase and high frequency response may decrease if source capacitance exceeds the recommended level. In some cases, low frequency oscillation of the output may occur. The maximum recommended level in pF's is determined using the following formula:

maximum recommended source capacitance = 10,000/422E sensitivity in mV/pC

For example, the level for a 422E02/E12 would be 10,000/10 pF = 1,000 pF, and the level for a 422E03/E13 would be 10,000 pF. If PCB 003 type low noise cable is used, these values correspond to 10 meters and 100 meters of length respectively.

422E series models for use with high temperature sensors

The 422E35 (1 mV/pC) and 422E36 (10 mV/pC) have been specifically designed to operate with the lower insulation resistance values which piezoelectric sensors may exhibit when subjected to very high temperatures (generally greater than 500° F). Both units will operate with insulation resistances as low as $10k\Omega$.

Note: Because of the special circuitry required, the 422E35 and 422E36 have somewhat higher noise and longer turn on time than the equivalent units designed for use with sensors with high insulation resistance (the 422E03 and 422E02 respectively). Consult the **specifications** for details.

Caution! Excessive accumulated charges on the input cables can destroy the field effect transistor (FET) in the amplifier. These charges can be grounded by shorting the center pin on the cable connector plug to its knurled nut with any metallic object.



422E series models for use in radioactive environments

The 422E65 (1mV/pC) and 422E66 (10mV/pC) were designed to offer resistance to the effects of radiation exposure up to 1 Mrad Integrated Gamma Flux or 10¹⁰ N/cm² of Integrated Neutron Flux. They are also designed to operate with lower insulation values which piezoelectric sensors may exhibit when subjected to the high temperatures that generally accompany high levels of radioactivity.

warning 1 – ESD sensitivity

The power supply/signal conditioner should not be opened by anyone other than qualified service personnel. This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid injury.

warning 2 – ESD sensitivity

This equipment is designed with user safety in mind; however, the protection provided by the equipment may be impaired if the equipment is used in a manner not specified by PCB Piezotronics, Inc.

caution 1 – ESD sensitivity

Cables can kill your equipment. High voltage electrostatic discharge (ESD) can damage electrical devices. Similar to a capacitor, a cable can hold a charge caused by triboelectric transfer, such as that which occurs in the following:

- Laying on and moving across a rug,
- Any movement through air,
- The action of rolling out a cable, and/or
- Contact with a non-grounded person.

The PCB solution for product safety:

- Connect the cables only with the AC power off.
- Temporarily "short" the end of the cable before attaching it to any signal input or output.





caution 2 – ESD sensitivity

ESD considerations should be made prior to performing any internal adjustments on the

equipment. Any piece of electronic equipment is vulnerable to ESD when opened for adjustments. Internal adjustments should therefore be done ONLY at an ESD-safe work area. Many products have ESD protection, but the level of protection may be exceeded by extremely high voltage.

warranty

PCB instrumentation is warranted against defective material and workmanship for 1 year unless otherwise expressly specified. Damage to instruments caused by incorrect power or misapplication, is not covered by warranty. *If there are any questions regarding power, intended application, or general usage, please consult with your local sales contact or distributor.* Batteries and other expendable hardware items are not covered by warranty.

service

Because of the sophisticated nature of PCB instrumentation, field repair is typically **NOT** recommended and may void any warranty. If factory service is required, return the instrumentation according to the "Return Procedure" stated below. *A repair and/or replacement quotation will be provided prior to servicing at no charge.* Before returning the unit, please consult a factory PCB applications engineer concerning the situation as certain problems can often be corrected with simple on-site procedures.

return procedure

To expedite returned instrumentation, contact a factory PCB applications engineer for a RETURN MATERIAL AUTHORIZATION (RMA) NUMBER. Please have information available such as model and serial number. Also, to insure efficient service, provide a written description of the symptoms and problems with the equipment to a local sales representative or distributor, or contact PCB if none are located in your area.



Customers outside the U.S. should consult their local PCB distributor for information on returning equipment. For exceptions, please contact the International Sales department at PCB to request shipping instructions and an RMA. For assistance, please call (716) 684-0003, or fax us at (716) 684-3823. You may also receive assistance via e-mail at **electronics@pcb.com** or visit our web site at **www.pcb.com**.

customer service

PCB guarantees **Total Customer Satisfaction**. If, at any time, for any reason, you are not completely satisfied with any PCB product, PCB will repair, replace, or exchange it at no charge. You may also choose, within the warranty period, to have your purchase price refunded.

PCB offers to all customers, at no charge, 24-hour phone support. This service makes product or application support available to our customers, day or night, seven days a week. When unforeseen problems or emergency situations arise, call the **24 Hour SensorLine at 716 684-0001**, and an application specialist will assist you.



3425 Walden Avenue, Depew, NY 14043-2495 Phone 716 684-0001 Fax 716 684-0987 E-Mail <u>electronics@PCB.com</u> PCB <u>www.PCB.com</u> IMI <u>www.IMI-Sensors.com</u> Key <u>www.KeyTransducers.com</u>

ISO 9001 Certified

© 2001 PCB Group, Inc. In the interest of constant product improvement, specifications are subject to change without notice. All prices are subject to change without notice. PCB, ICP and Modally Tuned are registered trademarks of PCB Group, Inc. TORKDISC is a trademark of Key Transducers, Inc. Swiveler and Spindler are trademarks of PCB Group, Inc. IMI, SensorLine and Sensors that measure up! are service marks of PCB Group, Inc. All other trademarks are properties of their respective owners.

Model Number		N I INE CHABGE CONVERTER		on: B
422E21				: 22700
Performance Sensitivity (+ 5 %) (Charge Conversion)	D4 m///PC	<mark>SI</mark> ۱۵ ۳۷//م۲	OPTIONAL VERSIONS	-
	6250 pC	6250 pC	Optional versions have treatical specifications and accessories as listed for the standard model except where noted below. More than one option may be used.	standard model
Uverrange	±3 < 1 H-	± 3 <		
High Frequeancy Response (2.2 mA)	50 kHz		Temperature Rande Orbital Metriory and Contrinumication Compliant with IEEE P1451.4 Temperature Rande (Oberation)	۲1451.4 ۲۵۶ °C
High Frequeancy Response (4 mA)	75 kHz	75 kHz [3]	Output Bias Voltage 13.35 to 14.85 VDC 13.	4.85 VDC
High Frequeancy Response (20 mA)	100 kHz			
Non-cineany Environmental	≤ 1.0 % FS	≤ 1.0 % FS		
Temperature Range (Operating)	-65 to +250 °E	FA to 1121 °C		
Temperature Response (Sensitivity Deviation)	-00 10 7 200 F <1 %	-04 10 + 12 1 0 <1 %		
Maximum Shock	1000 g pk	9810 m/s ² pk		
Excitation Voltage Constant Current Excitation	+18 to 28 VDC	+18 to 28 VDC	10410	
Constant Current Lixeduation	2.2 10 20 MA + 2 5 V	2.2 to 20 mA + 3 5 V	NOLES: [1] Testad using voltana source and incut sourcides could be the feature of	-
	± 2.0 V <10 ahm	± 2.3 v <10 nhm	111 reside using voltage source and input capacitor equal to the reedback capacitor, to simulate a charge output sensor.	itor, to simulate
Output Bias Voltage	+12.75 to 14.25 VDC	+12.75 to 14.25 VDC	[2] Not to be used with low values of source resistance such as charge mode sensors at	nsors at
Output Polarity	Inverted	Inverted	elevated temperatures or contaminated sensor cables (preventing low frequency peaking	ncy peaking
Maximum Input Voltage	30 V		3	
Broadband Electrical Noise (1 to 10,000 Hz)	15 µV	-96 dB [1]	[4] See PCB Declaration of Conformance PS024 for details.	
Specifial Noise (10 Hz)	0.8 µV/√Hz			
Spectral Noise (100 HZ)	0.2 µV/√Hz			
Specifial Noise (1 KHZ)	0.07 µV/√Hz			
Spectral Noise (10 kHz)	0.07 µV/√Hz			
Resistance (Minimum required at input)	5,000,000 ohm	5,000,000 ohm [2]		
Discharge Lime Constant	≥ 0.5 sec	≥ 0.5 sec		
Source Capacitance Loading	0.0005 %/pF	0.0005 %/pF		
Privile Material				
riousing material Sealing	Noldod Hormotio	Violded Lermotic		
Size (Diameter x Length)	0.62 in x 3.62 in	16 mm x 92 0 mm		
Weight	2.46 oz	69.7 gm		
Electrical Connector (Input)	2-Pin MIL-C-26482	2-Pin MIL-C-26482		
Electrical Connector (Output)	2-Pin MIL-C-5015	2-Pin MIL-C-5015	~	
			Entered SLS Engineer: DN Sales: MLA Approved: Cn4 SF	Spec Number:
			Date: 10.20-05 Date: 10-12-05 Date: 10-20-05	12117
All specifications are at room temperature unless otherwise specified	ise specified.		SPLADIF70TP0////CC" Phone: 716-684-0001	001
In the interest of constant product improvement, we reserve the right to change specifications without notice.	irve the right to change specifi	ications without notice.	ją	
			3425 Walden Avenue, Depew, NY 14043	S@pcn.com

