

Model 686B1X/-0012

Smart Vibration Switch

Installation and Operating Manual

For assistance with the operation of this product, contact the PCB Piezotronics, Inc.

Toll-free: 800-959-4464 24-hour SensorLine: 716-684-0001 Fax: 716-684-3823 E-mail: imi@pcb.com Web: www.imi-sensors.com





PCB PIEZOTRONICS

Service, Repair, and Return Policies and Instructions

The information contained in this document supersedes all similar information that may be found elsewhere in this manual.

Service - Due to the sophisticated nature of the sensors and associated instrumentation provided by PCB Piezotronics, user servicing or repair is not recommended and, if attempted, may void the factory warranty. Routine maintenance, such as the cleaning of electrical connectors, housings, and mounting surfaces with solutions and techniques that will not harm the physical material of construction, is acceptable. Caution should be observed to ensure that liquids are not permitted to migrate into devices that are not hermetically sealed. Such devices should only be wiped with a dampened cloth and never submerged or have liquids poured upon them.

Repair – In the event that equipment becomes damaged or ceases to operate, arrangements should be made to return the equipment to PCB Piezotronics for repair. User servicing or repair is not recommended and, if attempted, may void the factory warranty.

Calibration – Routine calibration of sensors and associated instrumentation is recommended as this helps build confidence in measurement accuracy and acquired data. Equipment calibration cycles typically are established by the users own quality regimen. When in doubt about a calibration cycle, a good "rule of thumb" is to recalibrate on an annual basis. It is

also good practice to recalibrate after exposure to any severe temperature extreme, shock, load, or other environmental influence, or prior to any critical test.

PCB Piezotronics maintains an ISO-9001 certified metrology laboratory and offers calibration services, which are accredited by A2LA to ISO/IEC 17025, with full traceability to SI through N.I.S.T. In addition to the normally supplied calibration, special testing is also available, such as: sensitivity at elevated or cryogenic temperatures, phase response, extended high or low frequency response, extended range, testing, hydrostatic leak pressure testing, and others. For information on standard recalibration services or special testing, contact your local PCB Piezotronics distributor. sales or factory representative. customer service representative.

Returning **Equipment** – Following these procedures will ensure that your returned materials are handled in the expedient Before most manner. returnina any equipment to PCB Piezotronics, contact your local distributor, sales representative, or factory customer service representative to obtain a Return Warranty, Service, Repair, and Return Policies and Instructions Materials Authorization (RMA) Number. This RMA number should be clearly marked on the outside of all package(s) and on the packing

list(s) accompanying the shipment. A detailed account of the nature of the problem(s) being experienced with the equipment should also be included inside the package(s) containing any returned materials.

A Purchase Order, included with the returned materials, will expedite the turn-around of serviced equipment. It is recommended to include authorization on the Purchase Order for PCB to proceed with any repairs, as long as they do not exceed 50% of the replacement cost of the returned item(s). PCB will provide a price quotation or replacement recommendation for any item whose repair costs would exceed 50% of replacement cost, or any item that is not economically feasible to repair. For routine calibration services. the Order Purchase should include authorization to proceed and return at current pricing, which can be obtained a factory customer from service representative.

Contact Information – International customers should direct all inquiries to their local distributor or sales office. A

complete list of distributors and offices found at www.pcb.com. can be Customers within the United States may contact their local sales representative or factory customer service а representative. A complete list of sales representatives can be found at www.pcb.com. Toll-free telephone numbers for a factory customer service representative. in the division responsible for this product, can be found on the title page at the front of this manual. Our ship to address and general contact numbers are:

PCB Piezotronics, Inc. 3425 Walden Ave. Depew, NY14043 USA Toll-free: (800) 828-8840 24-hour SensorLineSM: (716) 684-0001 Website: www.pcb.com E-mail: info@pcb.com



PCB工业监视和测量设备 - 中国RoHS2公布表 PCB Industrial Monitoring and Measuring Equipment - China RoHS 2 Disclosure Table

	有害物 质					
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴 联苯 (PBB)	多溴二苯醚 (PBDE)
住房	0	0	0	0	0	0
PCB板	Х	0	0	0	0	0
电气连接器	0	0	0	0	0	0
压电晶体	Х	0	0	0	0	0
环氧	0	0	0	0	0	0
铁氟龙	0	0	0	0	0	0
电子	0	0	0	0	0	0
厚膜基板	0	0	Х	0	0	0
电线	0	0	0	0	0	0
电缆	Х	0	0	0	0	0
塑料	0	0	0	0	0	0
焊接	Х	0	0	0	0	0
铜合金 /黄 铜	Х	0	0	0	0	0
本表格依据 SJ/T	11364 的规注	定编制。				
O:表示 该有害物	勿质在该部件	所有均质	贡材料中	的含量均在 GB/T 2	6572 规定的限量要求以	下。
X:表示该有害物	顺至少在该	部件的某	其一均质;	材料中的含量超出	GB/T 26572 规定的限量	要求。
铅是欧洲RoHS指	令2011/65/	EU附件:	三和附件	四目前由于允 许的	豁免。	

CHINA RoHS COMPLIANCE

Component Name			Haza	rdous Substance	es	
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI Compounds (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	0	0	0	0	0	0
PCB Board	Х	0	0	0	0	0
Electrical Connectors	0	0	0	0	0	0
Piezoelectric Crystals	X	0	0	0	0	0
Ероху	0	0	0	0	0	0
Teflon	0	0	0	0	0	0
Electronics	0	0	0	0	0	0
Thick Film Substrate	0	0	Х	0	0	0
Wires	0	0	0	0	0	0
Cables	Х	0	0	0	0	0
Plastic	0	0	0	0	0	0
Solder	Х	0	0	0	0	0
Copper Alloy/Brass	Х	0	0	0	0	0

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement of GB/T 26572.

Lead is present due to allowed exemption in Annex III or Annex IV of the European RoHS Directive 2011/65/EU.

DOCUMENT NUMBER: 21354 DOCUMENT REVISION: **D** ECN: 46162



686-Series Smart Vibration Switch



Operating Guide with Enclosed Warranty Information

3425 Walden Avenue, Depew, New York 14043-2495

Phone (716) 684-0003

Fax (716) 684-3823

Toll Free Line 1-800-959-4IMI

MANUAL NUMBER: 40112 MANUAL REVISION: G ECO: 49766



Table of Contents

Introduction General Features	Page 3
Operating Principles Benefits of Solid State Relays	Page 4
Installation Direct Adhesive Mount Standard Stud Mount Adhesive Stud Mount Magnetic Mount	Page 5
Wiring	Page 9
Legend Indicating a High Level of Vibration in a Motor Indicating High Levels of Vibration Simultaneously in Series (Such as Fan & Motor) Constant Siren Alarming in the Event of High Vibration Levels Two Switches in Parallel to Monitor Two Aces Simultaneously on Same Motor Three Switches in Parallel to Monitor Three Motors Simultaneously Automatic Machinery Shutdown Using an External Electromechanical Relay Automatic Machinery Shutdown Using External Electromechanical Relay While Monitoring 2 Axe Switch and External Latching for Automatic Machinery Shutdown Both Alarm Siren and Automatic Machinery Shutdown Using Two Switches Automatic Machinery Shutdown Based on Normally Open Solid State Relay Automatic Machinery Shutdown of a Three Phase Electrical Motor Based on a N.O. Solid-State	te Relay
Programming Software Program Installation Running the Software Programming Sections Reading and Writing Parameters Parameter Options Execution of Delays	Page 21
Magnetically Adjustable Vibration Threshold (MAVT™) MAVT™ Procedure	Page 29
Factory-Programmed Ordering Guide	Page 30
Battery-Powered Signal Conditioner	Page 31
Calibration Cable	Page 31
Magnet Clip	Page 31
Cable Ordering Information	Page 32
ESD Sensitivity	
Warranty, Service & Return Procedure	
Customer Service	-



Introduction

The 686-Series Smart Vibration Switch is a low-cost electronic vibration switch designed to monitor vibration levels on rotating machinery (ie. fans and cooling towers) and trip an alarm or shut down machinery when a specified vibration limit is exceeded. An onboard accelerometer with precision, microprocessor-controlled electronics ensures reliable operation and accuracy. The switch contains a two-pin MIL connector for easy drop-in replacement of mechanical vibration switches and a reliable solid state relay. Multiple units can be installed in a loop configuration for economical installation and expanded protection of critical machinery. This versatile switch can be used to replace more expensive electronic vibration switches where separate vibration output is not required and to replace troublesome mechanical vibration switches.

Every Smart Switch is factory-programmed. See Page 28 for more information.

General Features

- Fully USB-programmable from any PC (with optional USB Programmer Kit).
- Hermetically-sealed, stainless steel housing for use in corrosive environments.
- Imbedded piezoelectric accelerometer for improved accuracy and frequency response.
- Small footprint and single 1/4-28 stud mounting.
- Solid state (AC/DC) relay.
- Universal AC or DC power.
- Magnetically Adjustable Vibration Threshold (MAVT[™]).
- Connects with industry standard MIL-C-5015 connector or integral cable.
- Programmable features
 - o Alarm threshold level
 - o Normally Open (NO) or Normally Closed (NC) relay
 - o Latching or non-latching relay
 - o Delays
 - Power on
 - Startup
 - Operational
 - Residual vibration level
 - Intrinsically-safe versions available (EX prefix)
 - o CSA



Operating Principles

The Smart Switch operates over just two wires. It installs in series with any load (ie. annunciator, PLC or relay coil). To energize itself, the vibration switch scavenges power from the load's power source. When the alarm threshold is exceeded, the switch is activated and the load's power circuit is completed to facilitate the desired alarm or shutdown.




Figure 1 – Block Diagram

Benefits of Solid State Relays

A solid state relay is an electronic component that functions in the same way as an electromechanical relay, but without any moving parts. A solid state relay offers the most reliable switch action, especially for vibration applications where moving relay components run a greater risk of malfunction. They are purely electronic devices composed of a low current control side and a high current load side for switching action.



Installation

When choosing a mounting method, consider closely the advantages and disadvantages of each technique. Typical mounting types are stud, direct adhesive, adhesive mounting base and magnetic mounting base.

Note: For a complete list of product specifications, see the "Specification Sheet" and "Outline Drawing" at the end of this Manual.

Direct Adhesive Mount Procedure

For restrictions of space or for convenience, most sensors (with the exception of integral stud models) can be adhesive-mounted directly to the machine surface.

- Step 1: Prepare a smooth, flat mounting surface. A minimum surface finish of 63 µin (0.0016 mm) generally works best.
- Step 2: Place a small portion of adhesive on the underside of the sensor. Firmly press down on the top of the assembly to displace any adhesive. Be aware that excessive amounts of adhesive can make sensor removal difficult.




Figure 2 – Direct Adhesive Mounting



Standard Stud Mount Procedure

This mounting technique requires smooth, flat contact surfaces for proper operation and is recommended for permanent and/or secure installations. Stud mounting is also recommended when testing at high frequencies.

Note: Do not attempt mounting on curved, rough or uneven surfaces, as the potential for misalignment and limited contact surface may significantly reduce the sensor's upper operating frequency range.

	1/4-28 Stud	1/4-28 Captive Screw
A (in)	0.250	0.250
B (in)	0.350	0.350
Torque (ft-lb)	2 to 5	2 to 5

- Step 1: First, prepare a smooth, flat mounting surface and then drill and tap a mounting hole in the center of this area. A precision-machined mounting surface with a minimum finish of 63 µin (0.0016 mm) is recommended. (If it is not possible to properly prepare the machine surface, consider using an adhesive mounting pad as a possible alternative.) Inspect the area, checking that there are no burrs or other foreign particles interfering with the contact surface.
- Step 2: Wipe clean the mounting surface and spread on a light film of grease, oil or similar coupling fluid prior to installation. Adding a coupling fluid improves vibration transmissibility by filling small voids in the mounting surface and increasing the mounting stiffness. For semi-permanent mounting, substitute epoxy or another type of adhesive.
- Step 3: Hand-tighten the sensor/mounting stud to the machine, and then secure the sensor with a torque wrench to the mounting surface by applying the recommended mounting torque (see enclosed specification data sheet for proper mounting torque). It is important to use a torque wrench during this step. Under-torqueing the sensor may not adequately couple the device; over-torqueing may result in stud failure and possibly permanent damage.




Figure 3 – Mounting Surface Preparation




Figure 4 – Mounting Surface Lubrication



Adhesive Stud Mount Procedure

Adhesive mounting is often used for temporary installation or when the machine surface cannot be adequately prepared for stud mounting. Adhesives like hot glue or wax work well for temporary mounts; two-part epoxies and quick-bonding gels provide a more permanent mount.

Note: Adhesively mounted sensors often exhibit a reduction in high-frequency range. Generally, smooth surfaces and stiff adhesives provide the best frequency response. Contact the factory for recommended epoxies.

This method involves attaching a base to the machine surface, then securing the sensor to the base. This allows for easy removal of the accelerometer.

- Step 1: Prepare a smooth, flat mounting surface. A minimum surface finish of 63 µin (0.0016 mm) generally works best.
- Step 2: Stud-mount the sensor to the appropriate adhesive mounting base according to the guidelines set forth in Steps 2 and 3 of the Standard Stud Mount Procedure.
- Step 3: Place a small portion of adhesive on the underside of the mounting base. Firmly press down on the assembly to displace any extra adhesive remaining under the base.




Figure 5 – Adhesive Installation of Mounting Base



Magnetic Mount Procedure

Magnetic mounting provides a convenient means for making portable measurements and is commonly used for machinery monitoring and other portable or trending applications.

Note: The correct magnet choice and an adequately prepared mounting surface are critical for obtaining reliable measurements, especially at high frequencies. Poor installations can cause as much as a 50% drop in the sensor frequency range.

Not every magnet is suitable for all applications. For example, rare earth magnets are commonly used because of their high strength. Flat magnets work well on smooth, flat surfaces, while dual-rail magnets are required for curved surfaces. In the case of non-magnetic or rough surfaces, it is recommended that the user first weld, epoxy or otherwise adhere a steel mounting pad to the test surface. This provides a smooth and repeatable location for mounting.




Figure 6 – Magnet Types

- Step 1: After choosing the correct magnet, inspect the unit to verify that the mounting surfaces are flat and smooth.
- Step 2: Stud-mount the accelerometer to the appropriate magnet according to the guidelines set forth in Steps 2 and 3 of the Standard Stud Mount Procedure.
- Step 3: Prepare a smooth, flat mounting surface. A minimum surface finish of 63 µin [0.0016 mm] generally works best. After cleaning the surface and checking for burrs, wipe on a light film of silicone grease, machine oil or similar-type coupling fluid.
- Step 4: Mount the magnet/sensor assembly to the prepared test surface by gently "rocking" or "sliding" it into place.

Note: Magnetically mounting accelerometers carelessly has the potential to generate very high (and very damaging) g levels. To prevent damage, install the assembly gently. If unsure, please contact the factory for assistance.



Wiring

On the following pages are eleven different wiring scenarios for the Smart Switch. The wiring legend below is applicable to all wiring diagrams.





Figure 7 – Wiring Diagrams Legend

For those wiring scenarios that suggest the use of an external electromechanical relay, IMI suggests Omron general purpose relays as listed below. Visit www.omron.com for more information.

Attribute		Omro	n Model Numb	er		
	MJN2C-	MJN2C-	MJN2C-	MJN2C-	MJN2C-	
	AC120	AC240	DC12	DC24	DC110	
Contact Form	2 Form C (DPDT)					
Relay Rated Resistive Load	10 A @ 240 VAC/28 VDC					
Service Life- Electrical (Min @Rated Loads)		100,000	operations "ave	rage"		
Relay Max Resistive Switching Capacity	2400 VA, 280 W	240 VAC	12 VDC	24 VDC	110 VDC	
Coil Nominal Voltage	120 \	VAC		1.2 W		
Coil Power Consumption			1.7 VA			
Coil Type		Ν	Ion-Latching			
Seal Type			Unsealed			
Termination Style		S	Socket Mount			
Operating Temperature Range	-45 to	+60 C	-45 to +70 C			
Operating remperature Range	with no icing or	vith no icing or condensation with no icing or condensation				
Dielectric Strength (AC for 1 min)	2500 VAC					
Approved Standards			UL, CSA			



Indicating a High Level of Vibration in a Motor




Figures 8 and 9 – Indicating a High Level of Vibration in a Motor

Pushing the Start pushbutton closes the M contacts and starts the motor. If the start-up delay option for the switch is enabled, the Smart Switch will not trip regardless of the vibration level during the specified delay time. After this delay, the vibration switch will be activated. If the vibration level exceeds the alarm threshold for a time period greater than the specified operational delay time, the relay will trip. This action will close the contact to the pilot lamp.

Since the NL (non-latching) option is specified, the pilot lamp will illuminate only while alarm threshold is exceeded. Should the vibration level drop below the alarm threshold value (based also on the specified hysteresis), the pilot lamp will turn off.



Indicating High Levels of Vibration Simultaneously in Series (Such as Fan & Motor)



Figures 10 and 11 – Indicating High Levels of Vibration Simultaneously in Series (Such as Fan & Motor)

The Smart Switches are hooked up in series and installed on the two most loaded bearings across the coupling in the horizontal direction. Pushing the Start pushbutton closes the M contacts and starts the motor and fan. If the start-up delay option for the switches is enabled, the Smart Switches will not trip during the specified startup delay time, regardless of the vibration level. After this delay, the switch relays will be activated if the vibration level on both machines exceeds the alarm threshold for a period greater than the specified operation delay time. This action will close the contact to the pilot lamp.

Since the NL (non-latching) option is specified, the pilot lamp will illuminate only while set threshold on both machines is exceeded. Should the vibration level for one or both of the machines drop below the threshold value (based also on the specified hysteresis), the pilot lamp will turn off.



Constant Siren Alarming in the Event of High Vibration Levels





Figure 12 – Constant Siren Alarming in the Event of High Vibration Levels

The Smart Switch is hooked up for automatic constant siren alarming when the alarm threshold level is exceeded. Pushing the Start pushbutton closes the M contact and starts the motor. If the start-up delay option for the switches is enabled, the Smart Switches will not trip during the specified startup delay time, regardless of the vibration level. After this delay, the switch relay will be activated if the vibration level exceeds the alarm threshold for a period greater than the specified operational delay time. This action will close the contact to the alarm siren and activate it.

Since the LA (latching) option is specified, the alarm siren will be constantly energized after this high vibration event, even if the vibration level should drop below the alarm threshold. The Reset pushbutton should be engaged to de-energize the alarm siren and return the system to its original monitoring condition.



Using Two Switches in Parallel to Monitor Two Axes Simultaneously on Same Motor



Figures 13 and 14 – Using Two Switches in Parallel to Monitor Two Axes Simultaneously on Same Motor


The Smart Switches are hooked up in parallel and installed on the motor in horizontal and vertical directions. Pushing the Start pushbutton closes the M contact and starts the motor. If the start-up delay option for the switches is enabled, then during the specified startup delay time, the switches will not trip regardless of the vibration level. After this delay, the alarm siren will be activated if either of the switches experiences a vibration level over the alarm threshold lasting greater than the specified operation delay time.



Since the NL (non-latching) option is specified, the alarm siren will sound while alarm threshold on one or both switches is exceeded. Should the vibration level for both switches drop below the alarm threshold value (based also on the specified hysteresis), the alarm siren will turn off.




Using Three Switches in Parallel to Monitor Three Motors Simultaneously



The three Smart Switches are hooked up in parallel and installed on each motor in the horizontal direction. This provides an economical solution for monitoring a group of machinery while only having to run one cable. Pushing any Start pushbutton will close the corresponding M contact and start the motor. If the start-up delay option for the switches is enabled, then during the specified startup delay time, the switches will not trip; regardless of the vibration level. After this delay, the pilot lamp will be illuminated if any of the switches experience a vibration level over the alarm threshold value lasting greater than the specified operational delay time.


Since the NL (non-latching) option is specified, the pilot lamp will illuminate while alarm threshold on any of the switches is exceeded. When the vibration level for all switches drops below their alarm threshold value (based also on the specified hysteresis), the pilot lamp will turn off.



Figures 15 and 16 – Using Three Switches in Parallel to Monitor Three Motors Simultaneously



Automatic Machinery Shutdown Using an External Electromechanical Relay




Figures 17 and 18 – Automatic Machinery Shutdown Using an External Electromechanical Relay

The Smart Switch is hooked up for automatic motor shutdown when the alarm threshold level is exceeded. The switch should be mounted in the horizontal direction on the bearing carrying the most load. Pushing the Start pushbutton closes the M contact and starts the motor. If the start-up delay option for the switches is enabled, the Smart Switches will not trip during the specified startup delay time, regardless of the vibration level. After this delay, the switch relay will be activated if the vibration level exceeds the alarm threshold for a period greater than the specified operational delay time. This action will close the contact and send a voltage to the RL relay coil. This will open the RL1 and close the RL2 contacts, shut down the motor, and light the pilot lamp.

Since the LA (latching) option is enabled, the RL coil will be constantly energized after this event; even if the vibration level drops below the alarm threshold value after shutdown. The Reset pushbutton should be pushed to reset the switch and close the RL1 and RL2 contacts before restarting the motor.



Automatic Machinery Shutdown Using an External Electromechanical Relay While Monitoring 2 Axes



Figures 19 and 20 – Automatic Machinery Shutdown Using an External Electromechanical Relay While Monitoring 2 Axes

The Smart Switches are hooked up in parallel for automatic motor shutdown when the alarm threshold level is exceeded on either switch. The switches should be mounted in the horizontal and vertical direction at the bearing carrying the most load. Pushing the Start pushbutton closes the M contact and starts the motor. If the start-up delay option for the switches is enabled, the Smart Switches will not trip during the specified startup delay time, regardless of the vibration level. After this delay, the switch relay will be activated if the vibration level of either switch exceeds the alarm threshold for a period greater than the specified operational delay time. This action will close the contact and send a voltage to the RL relay coil. This will open the RL contacts and shut down the motor.

Since the LA (latching) option is specified, the RL coil will be constantly energized after this event; even if the vibration level drops below the alarm threshold value after shutdown. The Reset pushbutton should be pushed to reset the switch and close the RL contacts before restarting the motor.



Using the Switch and External Latching for Automatic Machinery Shutdown




Figure 21 – Using the Switch and External Latching for Automatic Machinery Shutdown

The Smart Switches are hooked up for automatic motor shutdown in case of high vibration levels on critical machinery. Since RL2 contacts are normally closed, pushing the Start pushbutton closes the M contact and starts the motor. If the start-up delay option for the switches is enabled, the Smart Switches will not trip during the specified startup delay time, regardless of the vibration level. After this delay, the switch relay will be activated if the vibration level of either switch exceeds the alarm threshold for a period greater than the specified operational delay time. This action will close the contacts and send a voltage to the RL relay coil. This will open the RL2 contacts and shut down the motor.

Since the LA (latching) option is specified, the RL1 contacts are used for external latching. Closing of RL1 provides constant coil energizing after the shutdown event. Therefore, when the vibration level drops below the alarm threshold level after shutdown, the closed RL1 contacts still energize the RL coil and keep RL2 in the open position. The Reset pushbutton should be pushed to reset the 2-wire switch, close the RL2 contacts and open the RL1 contacts before restarting the motor.

Both Alarm Siren and Automatic Machinery Shutdown Using Two Switches




Figure 22 – Both Alarm Siren and Automatic Machinery Shutdown Using Two Switches

The Smart Switches are hooked up for providing alarm siren and automatic motor shutdown when the alarm threshold levels are exceeded. To accomplish this, the two switches have two different threshold values; one for alarm and one for shutdown. Pushing the Start pushbutton closes the M contact, and since RL2 contacts are normally closed, starts the motor. If the start-up delay option for the switch is enabled, the switch will not trip regardless of the vibration level during the specified delay time. After this delay, if the vibration level exceeds the alarm threshold for the alarm switch, it will be activated and apply a voltage to the alarm siren. Since the NL (non-latching) option is specified for this switch, the alarm siren will be energized until the vibration level falls below the alarm threshold value (based also on the specified hysteresis). If the vibration level exceeds the shutdown alarm threshold, the second vibration switch will be activated and apply a voltage to the RL relay coil. This will open the RL contacts and shut down the motor. Since the LA (latching) option is specified, the RL coil will be constantly energized after this event; even though the vibration level will drop below the alarm threshold value after shutdown. The Reset pushbutton should be pushed to reset the switch and close the RL contacts before restarting the motor.



Automatic Machinery Shutdown Based on Normally Open Solid-State Relay




Figure 23 – Automatic Machinery Shutdown Based on Normally Open Solid-State Relay

The Smart Switch is hooked up to provide automatic motor shutdown when the alarm threshold level is exceeded. Pushing the Start pushbutton closes the M contact, and since the switch is Normally Closed, the solid state relay will be energized and the RL contacts will be closed. This will start the motor. If the start-up delay option is enabled, the switch will not trip regardless of the vibration level during the specified delay time. After this delay, if the vibration level exceeds the alarm threshold, it will be activated, thereby opening its contacts and de-energizing the solid state relay input. This will open the RL contacts and shut down the motor. Since the LA (latching) option is specified, the solid state relay input will be constantly de-energized after this event even if the vibration level drops below the alarm threshold value after shutdown. The Reset pushbutton should be pushed to reset the switch and close the RL contacts before restarting the motor.



Automatic Machinery Shutdown of Three-Phase Electrical Motor Based on a N.O. Solid State Relay




Figure 24 – Automatic Machinery Shutdown of 3-Phase Electrical Motor Based on a N.O. Solid State Relay

The Smart Switch is hooked up to provide automatic motor shutdown when the alarm threshold level is exceeded using a normally open three channel solid state relay. Since the Smart Switch is normally closed, closing the Start Switch will energize the solid state relay. This will cause the RL1, RL2, and RL3 contacts to close and start the motor. If the start-up delay option for the switch is enabled, the switch will not trip regardless of the vibration level during the specified delay time. After this delay, if the vibration level exceeds the alarm threshold, it will be activated, thereby opening its contacts and de-energizing the solid state relay input. This will open the RL1, RL2, & RL3 contacts and shut down the motor. Since the LA (latching) option is specified, the solid state relay input will be constantly de-energized after this event; even if the vibration level drops below the alarm threshold value after shutdown. The Reset pushbutton should be pushed to reset the switch and close the RL1, RL2, & RL3 contacts before restarting the motor. This will start the motor immediately without using the Start pushbutton.



Programming Software

The Smart Switch can be user-programmed with the optional Model 600A29 Programming Kit. The kit includes USB programmer cable/dongle (Model 070A100), software (Model EE225), terminal block/integral cable adapter (Model 042M17) and magnet clip (Model 080A214). The software can also be downloaded from IMI's website, www.pcb.com. This software must be installed prior to connecting the Smart Switch to the computer using the USB programmer cable. The software includes both the drivers and user interface needed for programming the Smart Switch. During initial installation, you may need administrative rights for the computer in order to install the drivers. Once installed, administrative rights are not required for use.



Figure 25 – Model 600A29 USB Programmer Kit

Program Installation

Installing the Software and USB Driver: Insert the software CD provided into the CD drive. The software will start the installation automatically if your PC is set to auto-install applications. If not, browse the CD and click on Setup.exe to start the installation process. The default installation directory is C:\PCB\EE225. It is recommended to use the default setting.

The installer will first install the software and then the WinUSB device driver. This device driver is required for the programmer software to communicate with the 070A100 USB programmer cable included in the programmer kit.

The following screens will be displayed when the installer starts. Click the Next button to proceed from step to step.

Destination Directory Select the installation directories.	
All software will be installed in the following location, click the Browse button and select	locations. To install software into a different another directory.
Directory for PCB_EE225 Programmer	Brown
	Browse

Figure 26 – Install Location Screen





Figure 27 – National Instruments Software License Agreement




Figure 28 – Installation Verification Screen




Figure 29 – Installation Complete Screen



After the software completes, the USB driver installer will start automatically. The initial USB installer will look similar to the one below.

Installation Wizard! This wizard helps you install the software drivers that some computers devices need in order to work.
To continue, click Next.

Figure 30 – WinUSB Driver Installation Screen

The drivers will now be properly installed and you should get the following screen. Click "Finish". The software is now ready to use.

Completing the Do Installation Wizar	
The drivers were successfully in	nstalled on this computer.
You can now connect your dev	vice to this computer. If your device
came with instructions, please r	
came with instructions, please r	read them first.

Figure 31 – WinUSB Driver Installation Complete Screen



Running the Software

Connect the USB programmer cable to the Smart Switch. Hold a magnet to the indicated MAVT[™] point on the Smart Switch. Wait about 2 seconds. While keeping the magnet against the Smart Switch, connect the USB programmer cable to a USB port on the PC. Run the software from the Start | All Programs | PCB EE225 Software menu item.

Initially the screen will appear as in **Error! Reference source not found.** with a yellow bar and status indicating 'Initializing...' followed by the message: "Connecting to USB Dongle...".

	CB EE225 Software			
	Select Select Select Initializing Select a Device to proceed when the USB link is of The status bar at the top should turn bright green when the link is if this takes more than 10 seconds then disconnect & reconnect the U Read Parameters	made.	Set Parameters	Ţ

Figure 32 – Software While Connecting to USB Programmer Cable

Once the connection is made the bar at the top of the screen will turn green and the status will indicate "USB Connection Success - Select a device". If the software and USB programmer cable fail to connect, remove and reinsert the USB programmer cable.

	© PCB EE223 Software	- • ×
Unit	Jnits Help	
	Device Select Select Always use Device Select Select Istatus USB Connection Success - Select a device	
	Select a Device to proceed when the USB link is established The status bar at the top should turn bright green when the link is made. If this takes more than 10 seconds then disconnect & reconnect the USB dongle	
	Read Parameters Set Parameter	ers

Figure 33 – Software After Connecting to USB Programmer Cable



To select a device, click on the Device Select pull down menu and select the device you'd like to program. In this case, select 686.

PCB EE225 Software		
its Help		
Device Select		
Select	-	Always use Device Select after attaching a sensor.
✓ Select		ancer accounting a sensori
649A01		
649A03		
649A04		
686		
	ts Help Device Select Select ✓ Select 649A01 649A03 649A04	ts Help Device Select Select ▼ ✓ Select 649A01 649A03 649A04

Figure 34 – Device Selection

Once a product is selected, the software will prompt you to confirm connection of the sensor to the PC using the USB programmer cable. Click OK to proceed.

	e Device Select hing a sensor.	Status USB Connection Succes	s - Select a device
6% Ena Relay Contact Normally Closed Res	Power On Delay (sec) 3 Operational Delay 1 1 - 60 Click 'OK' when the (use a magnet to tu able 10 Sec tup Alarm Threshold idual Vibration Level pendent 10 % of Threshold ips pk	sensor is connected. rn on the 686C01) Cancel Relay Contact Relay Contact	o Alarm Threshold al Vibration Level

Figure 35 – Sensor Connection Screen

While the software is establishing communication with the sensor, the status will display 'Checking Status...' and the colored indicator box next to the status will alternate between red and yellow. This will take approximately 15 seconds. Once communication is established, the indicator box will turn green and the software will read the sensor's current settings and data. The fields presented in the main body of the screen will be specific to the selected sensor.



Programming Sections

The screen has two sections:

- Actual 686 Settings This section shows the settings currently programed in the sensor.
- 686 Settings to Write This section shows the options for programming the sensor.

	rs use Device Select attaching a sensor.		Status Done	
Actual 686 Settings			686 Settings to Write	
MAVT Enabled Alarm Threshold D.5 0.25 - 5.0 ips pk Hysteresis Kelay Contact Normally Open Latching Actual Vibration 0.1	Power On Delay (sec) 3 Operational Delay (sec) 6 1 - 60 Startup Delay Enable Startup Alam Threshold 2 Residual Vibration Level Dependent 5 % of Threshold Ibp pk	>>>	MAVT Enabled Alarm Threshold Alarm Threshold 0.25 - 5.0 ips pk Hysteresis 6% Relay Contact Normally Closed Latching	Power On Delay (sec) 3 Operational Delay (sec) 1 1 - 60 Startup Delay Enable 10 Seconds Startup Alarm Threshold 2 Residual Vibration Level Dependent 10 % of Threshold

Figure 36 – Typical Smart Switch Screen After Successful Parameter Read

Reading and Writing Parameters

- Reading Parameters To read the current sensor settings, click the Read Parameters button. This
 operation takes approximately 45 seconds to complete.
- Transferring Actual Settings to Settings to Write Field Use the '>>>' button to transfer all Actual Settings to the Settings to Write fields.
- Writing Parameters- Select the appropriate mode and enter any pertinent parameter information. Click the Set Parameters button. This causes the settings to be sent to the sensor and then read back and displayed in the Actual 686 Settings.

	s use Device Select attaching a sensor.	Status Done	
Actual 686 Settings		686 Settings to Write	
MAVT Enabled Alarm Threshold 0.5 0.25 - 5.0 ips pk Hysteresis 6% Relay Contact Normally Open Latching	Power On Delay (sec) 3 Operational Delay (sec) 6 1 - 60 Startup Delay Enable 3 Seconds Startup Alarm Threshold 2 Residual Vibration Level Dependent 5 % of Threshold	MAVT Enabled Alarm Threshold D 0.5 -5.0 ips pk Hysteresis 6% Relay Contact Normally Closed Latching	Power On Delay (sec) 3 Operational Delay (sec) 1 1 - 60 Startup Delay Enable 10 Seconds Startup Alam Threshold 22 Residual Vibration Level Dependent 10 % of Threshold

Figure 37 – Transferring Actual Settings to Settings to Write Field



Parameter Options

The software presents one read-only parameter (Actual Vibration) and several parameters that can be programmed to optimize performance of the Smart Switch. At any point during the programming process, the values can be changed between imperial and metric measurements by clicking the Units dropdown in the top navigation menu and then selecting the appropriate measurement type.


Parameter	Description	Acceptable Value(s)		
Actual Vibration	Actual vibration (ips pk) being sensed by the switch at time when Read Parameters button is clicked.	N/A		
MAVT™	Capability to determine and set the alarm threshold value automatically by the Smart Switch based on the actual vibration level measured by it. For more information about the MAVT [™] feature, see page 16.	Enabled Disabled		
Alarm Threshold	Vibration level at which the relay will change state.	0.25- 5.0 ips pk 6.35-127 mm/s pk		
Hysteresis	Percentage that actual vibration must fall below the alarm threshold in order for a non-latching relay to automatically reset itself. Hysteresis prevents a relay from continually changing states when the vibration level is hovering around the alarm threshold level.	3% 6% 10%		
Relay Contacts- Normal State	State in which the relay stays when not tripped.	Normally Open Normally Closed		
Relay Contacts- Reset State	 How the relay operates once actual vibration falls below the alarm threshold. Latching: Relay to latch or stay in the alarm state until manually reset regardless of the vibration level. Non-Latching Relay automatically resets once the vibration level falls below the alarm threshold (hysteresis) level. 	Latching Non-Latching		
Power On Delay	Specified time period immediately after power is applied to the switch during which the relay will not trip regardless of the vibration level. Prevents a relay trip during high transient vibration levels that may occur during a normal machine startup.	3 sec 20 sec		
Operation Delay	Specified time period for which actual vibration must constantly exceed the Alarm Threshold before the relay changes state. Prevents a relay trip as a result of a short transient spike in vibration level that may not even be caused by a machine fault.	1-60 sec		
Startup Delay- Status	Specified time period immediately after power is applied to the equipment being monitored during which the relay will not trip regardless of vibration level.	Enabled Disabled		
Startup Delay- Time Period	Time period during which vibration is ignored.	1-60 sec 1-30 min		
Startup Delay- Startup Alarm Threshold	Maximum vibration ignored during the time period. Calculated as a multiple of the Alarm Threshold.	2x 4x 8x Blocked (All vibration)		
Startup Delay- Residual Vibration Level	Minimum vibration level that, once surpassed at equipment startup, triggers the countdown of the Startup Delay Time Period.	Dependent (Threshold %) Independent (Value) Max 40% of Threshold		



Unless otherwise specified, the Smart Switch comes from the factory with a set of default parameters. The specific set of parameters depends on the last alphanumeric character in the model number.

		1	2	phanumeric Ch 3	4	X
	MAVT™		Ena	bled		
	Alarm Threshold		0.6	0 ips		
	Hysteresis		6	%		
	Relay Contacts- Normal State	Normally Open	Normally Closed	Normally Open	Normally Closed	
ter	Relay Contacts- Reset State	Latching	Latching	Non-Latching	Non-Latching	Custom,
Parameter	Power On Delay		Customer- Specific			
	Operation Delay		Configuration			
	Startup Delay- Status					
	Startup Delay- Time Period					
	Startup Delay- Startup Alarm Threshold					
	Startup Delay- Residual Vibration Level			endent hreshold		

Execution of Delays



Magnetically Adjustable Vibration Threshold (MAVT™)

Magnetically Adjustable Vibration Threshold (MAVT[™]) is a Smart Switch selectable feature via USB programming. This unique capability allows the alarm threshold value to be determined and set automatically by the Smart Switch based on the actual vibration level being measured by it. This convenient feature permits any machine to be protected by a vibration switch within seconds without knowing anything about its vibration levels.

The Smart Switch has no accessible mechanical adjustments (ie. screw pots or DIP switches) that are found on other style electronic vibration switches. However, when the MAVT[™] option is selected, the hermetically-sealed switch becomes adjustable through magnetic actuation. By touching a specified location on the housing with a strong permanent magnet for 2 seconds, an internal microprocessor is actuated that initiates the test sequence.

Note: The magnet clip (Model 080A214) is a supplied accessory when the Smart Switch is ordered from the factory with the optional 600A29 USB Switch Programmer Kit.



Figure 38 – Magnet Clip

MAVT[™] Procedure

Be absolutely sure you do not have the switch connected to the machine's trip circuit during this procedure as the trip relay is activated several times during the procedure and will cause the machine to shut down and turn on several times. This could cause damage to your machinery.

- 1. Mount the Smart Switch on the machine that the switch will monitor. Be sure that the machine is operating in a steady state condition. If it is not operating, turn the machine on and allow enough time for the vibration level to normalize before going to the next step.
- 2. Connect the switch to the power supply using an appropriate cable. Since the Smart Switch operates off universal power, any power supply that outputs 24-240 VDC or 24-240 VAC, 50/60 Hz will work. A simple 24V power supply/signal conditioner (Model 480C02) will also work well and has the added advantage of visually indicating when the calibration process has been completed via its built-in meter. Allow 30 seconds for the switch to power up.
- 3. Touch the permanent magnet to the target on the side of the switch for approximately 2 seconds to initiate the process.
- 4. The alarm threshold calibration process takes approximately 30 seconds. (The amount of time needed varies based on the difference between the previous and new alarm threshold values.) During this process, the unit will measure the average vibration amplitude, set the alarm threshold value to two times this average value and store this value in a non-volatile memory. The relay contacts open and close repeatedly during this process.
- 5. Disconnect the Smart Switch from the power supply.
- 6. The switch can now be permanently installed on the machine for protection.



Factory Programmed Ordering Guide




Figure 39 – Ordering Guide



Battery-Powered Signal Conditioner

Power supply/signal conditioner (Model 480C02) is for use with the Smart Switch when determining the alarm threshold level using the MAVT[™] feature. The built-in meter indicates when the process is complete. See www.pcb.com for product details.



Figure 40 – Battery Powered Signal Conditioner

Calibration Cable

The calibration cable (Model 052BR010AC) is a 10 foot, twisted-pair, shielded cable with a 2-Pin MIL type connector terminating to a BNC plug for use with 480C02 power supply and Smart Switch.



Figure 41 – Calibration Cable

Magnet Clip

The magnet clip (Model 080A214) is supplied as part of the optional 600A29 USB Programmer Kit or can be ordered separately for use with the MAVT[™].








Figures 42 and 43 – Magnet Clip with and without Smart Switch



Cable Ordering Information

Go to www.pcb.com for complete information on cables.





Warning 1 – ESD sensitivity

The power supply/signal conditioner should not be opened by anyone other than qualified service

personnel. This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid injury.

Warning 2 – ESD sensitivity

This equipment is designed with user safety in mind; however, the protection provided by the equipment may be impaired if the equipment is used in a manner not specified by PCB Piezotronics, Inc.

Caution 1 – ESD sensitivity

Cables can kill your equipment. High voltage electrostatic discharge (ESD) can damage electrical devices. Similar to a capacitor, a cable can hold a charge caused by triboelectric transfer, such as that which occurs in the following:

- Laying on and moving across a rug,
- Any movement through air,
- The action of rolling out a cable, and/or
- Contact with a non-grounded person.

The PCB solution for product safety:

- Connect the cables only with the AC power off.
- Temporarily "short" the end of the cable before attaching it to any signal input or output.

Caution 2 – ESD sensitivity

ESD considerations should be made prior to performing any internal adjustments on the equipment. Any piece of electronic equipment is vulnerable to ESD when opened for adjustments. Internal adjustments should therefore be done ONLY at an ESD-safe work area. Many products have ESD protection, but the level of protection may be exceeded by extremely high voltage.





Warranty

IMI instrumentation is warranted against defective material and workmanship for 1 year unless otherwise expressly specified. Damage to instruments caused by incorrect power or misapplication, is not covered by warranty. *If there are any questions regarding power, intended application, or general usage, please consult with your local sales contact or distributor.* Batteries and other expendable hardware items are not covered by warranty.

Service

Because of the sophisticated nature of IMI instrumentation, field repair is typically **NOT** recommended and may void any warranty. If factory service is required, return the instrumentation according to the "Return Procedure" stated below. *A repair and/or replacement quotation will be provided prior to servicing at no charge.* Before returning the unit, please consult a factory IMI applications engineer concerning the situation as certain problems can often be corrected with simple on-site procedures.

Return Procedure

To expedite returned instrumentation, contact a factory IMI applications engineer for a RETURN MATERIAL AUTHORIZATION (RMA) NUMBER. Please have information available such as model and serial number. Also, to insure efficient service, provide a written description of the symptoms and problems with the equipment to a local sales representative or distributor, or contact IMI if none are located in your area.

Customers outside the U.S. should consult their local IMI distributor for information on returning equipment. For exceptions, please contact the International Sales department at IMI to request shipping instructions and an RMA. For assistance, please call (716) 684-0003, or fax us at (716) 684-3823. You may also receive assistance via e-mail at **imi@pcb.com** or visit our web site at **www.pcb.com**.

Customer Service

IMI, a division of PCB Piezotronics, guarantees **Total Customer Satisfaction**. If, at any time, for any reason, you are not completely satisfied with any IMI product, IMI will repair, replace, or exchange it at no charge. You may also choose to have your purchase price refunded.

IMI offers to all customers, at no charge, 24-hour phone support. This service makes product or application support available to our customers, day or night, seven days a week. When unforeseen problems or emergency situations arise, call the **IMI Hot Line at (716) 684-0003**, and an application specialist will assist you.

Model Number 686B1X	SMART VIBRATION SWITCH						Revision: D ECN #: 49896	
erformance	ENGLISH	SI 4 E to 00 mm/s rms	[4]	Optional varians have identi	OPTIONAL VERSIONS cal specifications and accessorie		tandard mod-	
rm Threshold	0.25 to 5 in/sec pk	4.5 to 90 mm/s rms	[1]		noted below. More than one op		tanuaru model	
equency Range(± 3 dB)	420 to 60 kcpm	7 to 1,000 Hz	[1]	except where	noted below. More than one op	aon may be used.		
steresis(% < Alarm Threshold)	3; 6; or 10 %	3; 6; or 10 %	[1]	EX - Hazardous Area Approva	II- contact factory for			
sidual Vibration Level(Reference)	Dependent or Independent	Dependent or Independent		specific approvals Current Rating				
sidual Vibration Level (% Alarm Threshold)	1 to 40 %	1 to 40 %	[1]	Current Rating	100 mA CI I, Div 2, Groups A, B, C, D;	10 Fix CLI Division	0 mA	
VT(Sets Alarm Threshold to 2X actual	Enabled or Disabled	Enabled or Disabled	[1]	Hazardous Area Approval	nL IICT3, AEx nA IICT3	EX CLI, DIV 2, Gro	AEx nA IICT3	
ration)				Power Required	10 to 30 VDC	10 to	30 VDC	
insverse Sensitivity	< 3 %	< 3 %		Relay	10 to 30 VDC, 100 mA	10 to 30 V	/DC, 100 mA	
wer On Delay	3 or 20 sec	3 or 20 sec	[1]	-				
irtup Delay(Time)	1 to 60 sec or 1 to 30 min	1 to 60 sec or 1 to 30 min	[1]	M - Metric Mount				
rtup Delay(x Alarm Threshold)	x2; x4; x8; Blocked	x2; x4; x8; Blocked	[1]	Optional Accessory: Model MU	81A61 Mounting Stud 1/4-28 to	5 M6 X 1 (1)		
rtup Delay (Active)	Enabled or Disabled	Enabled or Disabled	[1]					
erational Delay	1 to 60 sec	1 to 60 sec	[1]					
ay(Type)	SPST, Form A or B MOSFET	SPST, Form A or B MOSFET						
ay(Capacity)	24 to 240 V AC/DC, 500 mA	24 to 240 V AC/DC, 500 mA						
ay(Latching)	Latching / Non-Latching	Latching / Non-Latching						
ay (Contacts)	Normally Open / Closed	Normally Open / Closed						
vironmental	·	-						
mperature Range(Operating)	-40 to 185 °F	-40 to 85 °C						
nperature Range(Storage)	-40 to 257 °F	-40 to 125 °C						
erload Limit(Shock)	5,000 g pk	49,050 m/s ² pk						
midity Range(Condensing)	0 to 100 %	0 to 100 %						
closure Rating	IP67	IP67	[2]					
ectrical								
wer Required	24 to 240 V DC/AC 50/60 Hz	24 to 240 V DC/AC 50/60 Hz						
rrent Rating(Relay Closed)	500 mA	500 mA						
ak Current(Relay Open)	1 mA	1 mA						
ctrical Isolation(Case)	> 10 ⁸ Ohm	> 10 ⁸ Ohm						
	> 10° Unm	> 10° Onm						
nysical	1.05	1.05						
e - Hex	1.25 in	1.25 in						
e - Height	2.6 in	66 mm						
light	5.2 oz	148 gm						
ounting Torque	3 to 5 ft-lb	4 to 7 Nm						
ounting Thread	1/4-28 Female	1/4-28 Female						
nsing Element(Internal)	Piezoelectric Accelerometer	Piezoelectric Accelerometer						
using Material	Stainless Steel	Stainless Steel		NOTES:				
aling	Welded Hermetic	Welded Hermetic			e			
ctrical Connector	Molded Integral Cable	Molded Integral Cable			onfiguration sheet supplied with			
ble Length	10 ft	3 m			ly, customer is responsible for s	ealing at cable tern	nination	
ble Termination	Blunt cut	Blunt cut		[3]See PCB Declaration of Cor	formance PS096 for details.			
ctrical Connection Position	Тор	Тор						
ble Type	Polyurethane (Model 052)	Polyurethane (Model 052)						
	-	-						
				SUPPLIED ACCESSORIES				
				Model 081A41 Mounting stud	I/4-28 socket head set screw br	ass tip stainless ste	el 5/8"	
				long (1)				
				- 3.17				
					-			
				Entered: LK Engineer: B	AM Sales: MC A	pproved: BAM	Spec Number:	
£6.				Date: 08/22/2019 Date: 08/22	2/2019 Date: 08/22/2019 D	ate: 08/22/2019	41977	
U.						Phone: 800-9	E0 4464	
- 03				Sala ALCENCI	DC	Fax: 716-684-		
					כת			
specifications are at room temperature	unless otherwise specified					E-Mail: imi@p		

